



1 800 463 0546

# Early Birds Your GM Muscle Car Headquarters

Visit [www.early-birds.ca](http://www.early-birds.ca) for most up-to-date  
catalog this copy was generated March 29 2024

## Chevy Nova / Engine & Compartment / Brackets & Spacers

Picture	Product name	Description	SKU	CAD
	1962-1967 Power Steering Hose Bracket	This is a reproduction of the bracket that attaches the two power steering hoses to the inside of the left side frame rail. This steel bracket holds the hoses that run from the power steering pump to the power steering control valve, although the hoses are different for 6 cylinder and V8, this bracket will work on both applications. Comes with all mounting hardware.	NVICPS92	100.78
	1962-1967 Power Steering Hose Retainer	Correct reproduction of the original power steering hose clamp found on 1962-67 Nova models. Bolts to the power steering hose bracket.	NVICC832781	36.94
	1964-1968 Mounting Brackets GM A6 Complete Set (Small Block)	Replace your original compressor brackets with this comprehensive reproduction set, guaranteed to fit and function properly. Set includes: front brace, Front bracket, lower support, rear bracket, rear shim, all necessary hardware. For use on small blocks with short water pump and stock exhaust manifolds.	NVICAP199R	386.38
<b>Early Birds Order Hotline: 1 800 463 0546</b>				
	1964-1972 Alternator Bracket Spacer	Replacement alternator bracket spacer for 1964-1980 V-8 models with a 42, 55 or 61 amp alternator, and 1970-1975 6 cylinder models. Cut to length as required. Spacer is 1" in length.	NVIC3825451	3.34
	1964-1974 Distributor Hold Down Clamp	Reproduction of the distributor clamps used on GM small and big block engines from 1964-75. Correct replacement for this commonly bent or worn item.	NVICK1665	25.18
	1965-1967 Power Steering Pump Adjust Bracket	Correct power steering adjuster bracket for use on small block models	NVICC581381	63.82
	1965-1968 Alternator Mount Support (Small Block)	This is the correct support brace for 1965-68 small block Nova models. This bracket mounts on the leading edge of the drivers side exhaust manifold and supports the bottom of the alternator. Note: Not for use with 62 amp alternator.	NVICK6565	40.30
	1965-1970 SMALL BLOCK ENGINE LIFT BRACKET SET	Small Block Engine Lift Bracket Set. Heavy stamped steel. Accurate reproduction of originals for listed applications.	NVHQW931	44.72



	1965-1972 Power Steering Hose Retainer	Reproduction of the high pressure hose retainer which was bolted to the steering box cap.	NVICH83	13.42
	1966-1967 Correct Coil Bracket (w/bolt) - 35 degree	Proprietary tooling in 2017. OEM Thickness stamped steel. Exact fit, superior workmanship. Coil bracket includes correct shouldered, head and tip retaining screw as original. Each bracket has correct angle to ensure proper fitment, clear zinc plated. All application are from pre-1972 GM parts manuals. Later GM books add older applications due to superseded part numbers. GM Part #: 1966876Applications: 67 Camaro 327 4BBL., 69 Camaro 302 & 350 with cowl hood, 70-72 Camaro Z-28, 68 Corvette exc. 427, 69 Corvette exc. T Ign. & 427, 70-72 Corvette 350, 66-67 Chevy II & Chevelle 327 exc. HP.	NVHQR146	31.92
	1967-1968 Power Steering Bracket Kit (2 Piece)	Superior reproduction BB cradle bracket deep drawn, one piece stamped steel as original, with factory logo mark. Excellent reproduction rear brace includes crimps as original. Technically correct set with accurate alignment geometry. Coated black. Officially Licensed GM Restoration Parts.	NVHQW798	143.92
	1967-1968 Power Steering Cradle Bracket Big Block	Accurate reproduction in original very heavy gauge stamped steel. Cradle is deep drawn, stamped from one piece as original. Includes factory stamping mark. Coated black. Technically correct. Packaged in a color logo box. Officially Licensed GM Restoration Parts.	NVHQW688	111.92
	1967-1968 Power Steering Rear Brace Big Block	Faithfull reproduction in original heavy gauge stamped steel. Indents and crimps as original. Coated black. Officially Licensed GM Restoration Parts.	NVHQW689	52.72
	1967-1972 Alternator Bracket Negative Battery Cable Retainer (Small Block)	Reproduction of the negative battery cable retainer clip that snaps into a hole on the upper alternator bracket on 1967-72 Chevrolet small block engines. This retainer clip is also used in some applications to hold the battery cable to the subframe.	NVIC3857706	20.14
	1967-1974 Fan Spacer GM#3927793	(1967-81 GM Cars) 2-3/8" FAN SPACER GM #: 3927793 - MEASURES 2.28" ACROSS W/ 1.25" BOLT SPACINGFits: Misc. 1967-81 GM Vehicles without clutch style fan	NVPPZCS6821Z	63.98
	1968 Air Conditioning Compressor Front Support Brace (396/427)	396 427 BIG BLOCK AIR CONDITIONING COMPRESSOR FRONT SUPPORT BRACE GM # 3872734FITS: 66-68 CHEVELLE, EL CAMINO, 67-68 CAMARO, 65-68 IMPALA, 68 NOVA CHEVY II	NVPPZ3872734	47.98
	1968 Air Conditioning Compressor Rear Support Brace (396/427)	396 427 BIG BLOCK AIR CONDITIONING REAR SUPPORT BRACE GM # 3872720FITS: 66-68 CHEVELLE, EL CAMINO, 67-68 CAMARO, 65-68 IMPALA, 68 NOVA CHEVY II	NVPPZ3872720	41.58
				

	1968 Air Conditioning Compressor Rear Support Bracket (396/427)	396 427 BIG BLOCK AIR CONDITIONING COMPRESSOR REAR SUPPORT BRACKET GM # 3878268FITS: 66-68 CHEVELLE, EL CAMINO, 67-68 CAMARO, 65-68 IMPALA, 68 NOVA CHEVY II	NVPPZ3878268	31.98
	1968 Big Block Power Steering Adjustor Bracket	Correct reproduction of the original big block power steering bracket	NV3876788	58.78
	1968 BIG BLOCK UPPER ALTERNATOR BRACKET	Quality stamping from original thickness material. Faithfull factory appearance and function for big blocks. Includes correct throttle return spring bracket. Gloss black. Officially Licensed GM Restoration Parts.	NVHQB888	47.92
	1968 Compressor Mounting Brace (Front, Small/Big Block)	Reproduction of the original AC compressor mounting brace used to keep the air conditioning compressor supported in the correct position. The brace mounts between the intake manifold and the large AC compressor front mounting bracket.Applications: 1965-68 big block models1966-67 283ci, 327ci small block models	NVICC66821	41.98
	1968 Compressor Mounting Brace (Rear, Big Block)	Reproduction of the original AC compressor mounting brace used to keep the air conditioning compressor supported in the correct position. The brace mounts between the rear of the AC compressor and the intake manifold.	NVICC727201	41.98
	1968 Correct Coil Bracket (w/bolt) - 30 degree	Proprietary tooling in 2017. OEM Thickness stamped steel. Exact fit, superior workmanship. Coil bracket includes correct shouldered, head and tip retaining screw as original. Each bracket has correct angle to ensure proper fitment, clear zinc plated. All application are from pre-1972 GM parts manuals. Later GM books add older applications due to superseded part numbers. GM Part #: 1971011Applications: 68 Camaro 302, 69 Camaro 302 without Cowl hood, 68 Nova 327 Special HP, 68 Chevelle 327 Special HP.	NVHQR147	31.92
	1968 Lower Alternator Bracket Big Block Cast Iron 396	Exact cast iron reproduction of original 67-68 block mounted alternator bracket.	NVHQB436	87.92
	1968 Small Block Power Steering Adjustor Bracket	Correct reproduction of the original small block power steering bracket	NV3905366	50.38
	1968 Smog Air Pump Bracket (396/427)	396 427 SMOG AIR PUMP BRACKET GM # 3896983FITS: 66-68 CHEVELLE, EL CAMINO, 67-68 CAMARO, 65-68 IMPALA, 68 NOVA CHEVY II	NVPPZ3896983	191.98
	1968 SS-350 P/S BRACKET SET	Correct reproduction 67 standard door panel emblems adhesive backed. Pair. Officially Licensed GM Restoration Parts.	NVHQB095	127.92

	1968 SS-350 P/S CRADLE BRACKET	Exact reproduction of factory original power steering pump cradle bracket.. Accurately stamped steel, dimensionally correct. Coated black. Cradle bracket only. Officially Licensed GM Restoration Parts.	NVHQW095A	67.12
	1968 SS-350 P/S REAR BRACE	Exact reproduction of factory original power steering pump rear brace. Accurately stamped steel, dimensionally correct. Coated black. Rear brace only. Officially Licensed GM Restoration Parts.	NVHQW095B	47.92
	1968-1970 BIG BLOCK ENGINE LIFT BRACKET SET	Big block Engine Lift Bracket Set. USA made heavy stamped steel. Accurate reproduction of originals for listed applications.	NVHQW930	47.92
	1968-1972 AC Compressor Mounting Stud - PR	Correct replacement stud used to mount the AC compressor on all 1968 big block engines.	NVIC1256625	35.26
	1968-1972 BIG BLOCK ENGINE BRACKET SET	Engine, alternator and power steering brackets to install any 1969-72 (long neck water pump) big block engine. Includes all our individually available officially licensed high quality reproductions: Upper and lower alternator brackets, rear spacer and brace, hardware, power steering bracket set and engine frame mounts. Officially Licensed GM Restoration Parts.	NVHQW621	254.40
	1968-1972 Power Steering/Alternator Mounting Stud (Big Block)	Correct replacement stud used for the power steering or alternator mounting. 1 required per vehicle.	NVIC1256624	13.42
	1968-1974 Correct Coil Bracket (w/bolt) - 25 degree	Proprietary tooling in 2017. OEM Thickness stamped steel. Exact fit, superior workmanship. Coil bracket includes correct shouldered, head and tip retaining screw as original. Each bracket has correct angle to ensure proper fitment, clear zinc plated. All application are from pre-1972 GM parts manuals. Later GM books add older applications due to superseded part numbers. GM Part #: 1970344Applications: 67-68 Corvette 427, 69 Corvette 427 with T. Ign., 70-72 Corvette 454, 67 Camaro 327 2bbl., 68-69 Camaro 307, 327, 350, 396 exc. Cowl hood, 70-72 Camaro exc. Z-28, 68 Chevy II 327 exc. HP, 69-74 Nova V-8, 68 Chevelle 327 exc HP., 69-72 Chevelle, 71-72 Monte Carlo, 68-70 Fullsize Chevy exc. PG, 71-72 Fullsize Chevy exc. 400 & 454, 68-72 Chevy Truck exc. tilt.	NVHQR145	31.92
	1969 Power Steering Bracket Kit (3 Piece) Big Block	Power steering pump bracket set includes all three correct reproduction stamped steel brackets and the water pump mounting long pivot bolt. Black finish. Accurate stampings for 1969 Big Block Chevy engines. Officially Licensed GM Restoration Parts.	NVHQW418	103.92
	1969 Power Steering Bracket Kit (3 Piece) Small Block	Correct reproductions for use with long neck water pump small block engines. Crisp stampings. All three brackets needed. OE gauge, correct appearance and geometry. Officially Licensed GM Restoration Parts.	NVHQW799	127.92
				

	1969 Power Steering Small Rear Support Bracket Big Block	Correct reproduction pump brace only for 1969 Big Block Chevy engines. Officially Licensed GM Restoration Parts.	NVHQW418A	31.92
	1969-1970 A/C Compressor Rear Upper Bracket (Small Block)	REAR UPPER AIR CONDITIONER COMPRESSOR BRACKET FITS SMALL BLOCK MOTORS 307/350/400 GM # 3932436 FITS: 1969-70 CHEVROLET VEHICLES WITH 307, 350, or 400 CUBIC INCH SMALL BLOCK ENGINES	NVPPZ3932436	63.98
	1969-1970 FRONT A/C COMPRESSOR BRACKET - 1st DESIGN	HEAVY CAST IRON BRACKET MOUNTS TO FRONT OF HEAD BIG BLOCK 1ST DESIGN (GM PART # 3940948)	NVPPZUACB6970	111.98
	1969-1970 FRONT A/C COMPRESSOR PLATE BRACKET - 1st DESIGN	MOUNTS ON FRONT OF COMPRESSOR HAS ADJUSTMENT SLOT ON TOP BIG BLOCK 1ST DESIGN (GM PART # 3940949)	NVPPZFCPB6970A	63.98
	1969-1970 LOWER A/C COMPRESSOR BRACKET - 1st DESIGN	CAST IRON MOUNTS ON HEAD AND REAR OF COMPRESSOR WILL ADJUST ON BIG BLOCK 1ST DESIGN (GM PART # 3969912)	NVPPZLCB6970	63.98
	1969-1970 LOWER A/C COMPRESSOR BRACKET - 2nd DESIGN	This is a new 1969-1970 Chevelle / Camaro / Nova / Impala / El Camino & 1970 Monte Carlo lower A/C compressor bracket for big block. Hard item to find, it is a cast iron part. Replaces GM # 3969912.	NVPPZLCB6970A	63.98
	1969-1970 REAR A/C COMPRESSOR BRACKET - 1st DESIGN	GOES FROM REAR OF COMPRESSOR TO INTAKE FOR REAR ADJUSTMENT BIG BLOCK 1ST DESIGN (GM PART # 3940947)	NVPPZRCSB6970A	63.98
	1969-1970 REAR A/C COMPRESSOR PLATE BRACKET - 1st DESIGN	MOUNTS ON BACK OF COMP (GM PART #3932493)	NVPPZRCPB6970A	30.38
	1969-1970 REAR A/C COMPRESSOR SPACER - 1st DESIGN	MOUNTS BETWEEN COMPRESSOR AND REAR COMPRESSOR MOUNTING BRACKET BIG BLOCK 1ST DESIGN (GM PART # 3932437)	NVPPZRCS6970A	38.38
	1969-1972 Alternator Bolt Set (5 Pieces) Big Block	Heat treated long pivot stud bolt, nut, small adjusting bracket bolt, lock washer, and special thick washer. Black oil finish.	NVHQW736	20.72
	1969-1972 Alternator Bolt Small Block	Excellent quality reproduction manufactured to duplicate the original in both fit and appearance.	NVHQW737	15.92
				

	1969-1972 Alternator Bracket Set (3 Piece) 396	Our original 4 piece set packaging remains available: upper alternator brace, lower water pump brace and stud bolt with nut included. Accurate, crisp and clean stampings for 69-72 Big block engines. Gloss black finish. Officially Licensed GM Restoration Parts.	NVHQW417	103.92
	1969-1972 Alternator Bracket Set (7 Pieces) Small Block	Correct reproductions for use with long neck water pump small block engines. Crisp stampings. Original gauge. Lower brace faithful reproduction of original unlike current GM replacement piece that will not allow smog installation. High quality 7 piece bracket set includes upper and lower brackets, rear spacer and brace, lower pivot bolt with correct "RBW" head mark and upper mounting hardware including the special thick washer. Officially Licensed GM Restoration Parts.	NVHQW789	111.92
	1969-1972 Alternator Stud and Bolt Big Block	Excellent quality reproduction manufactured to duplicate the original in both fit and appearance.	NVHQW417A	15.92
	1969-1972 BIG BLOCK ALTERNATOR BRACKET SET - 9 PCS	Original heavy gauge stamped steel reproductions. Top bracket, lower front bracket, rear spacer and brace with logo mark and pivot stud bolt set with hardware. Accurate original gauge stampings. All parts with factory original finish. All technically correct brackets and hardware needed for big block alternator installation on 69 (long neck water pump) engine installation. Nine piece set. Officially Licensed GM Restoration Parts.	NVHQW779	127.92
	1969-1972 BIG BLOCK UPPER & LOWER ALT BRACKET SET	Accurate reproductions. Quality stampings with original thickness material and factory appearance. Bracket set includes a technically correct upper bracket and lower to water pump brace for 69-72 big block Chevy engines. Gloss black. Officially Licensed GM Restoration Parts.	NVHQW417B	79.92
	1969-1972 BIG BLOCK UPPER & LOWER ALT BRACKET SET (W/BOLT)	Accurate reproductions. Quality stampings with original thickness material and factory appearance. Bracket set includes a technically correct upper bracket and lower to water pump brace for 69-72 Big Block Chevy engines.. Gloss black. Officially Licensed GM Restoration Parts.	NVHQW417E	79.92
	1969-1972 FAN SPACER 3927792	CORRECT RARE FAN SPACER USED ON HIGH PERFORMANCE MOTORS WITHOUT FAN CLUTCH. IT IS 1" THICK	NVPPZ0516	63.98
	1969-1972 Lower Alternator Bracket Small Block	Technically correct reproduction for use with long neck water pump small block engines. Crisp stamping. Lower brace is an exact reproduction of original unlike the current GM replacement piece that will not allow smog installation. Officially Licensed GM Restoration Parts.	NVHQW787	27.12
	1969-1972 Power Steering Bracket "S" Side Bracket Small Block	Correct reproduction power steering pump "s" shaped side adjusting brace for use with long neck water pump small block engines. OE gauge, accurate stamping. Officially Licensed GM Restoration Parts.	NVHQW799C	39.92

	1969-1972 Power Steering Bracket Cradle Small Block	Correct reproduction power steering pump rear brace for use with long neck water pump small block engines. OE gauge, accurate stamping. Officially Licensed GM Restoration Parts.	NVHQW799A	55.92
	1969-1972 Power Steering Bracket Rear Brace Small Block	Correct reproduction power steering pump cradle bracket for use with long neck water pump small block engines. OE gauge, accurate stamping. Officially Licensed GM Restoration Parts.	NVHQW799B	52.72
	1969-1972 Rear Alternator Brace/Spacer Set	Faithfull reproduction rear alternator bracket and spacer set for big blocks. Includes original stamped logo mark on plated brace and correct rounded ends on spacer with black finish. Officially Licensed GM Restoration Parts.	NVHQW786	38.32
	1969-1972 Rear Alternator Bracket and Spacer Small Block	Correct quality reproduction for use with long neck water pump small block engines. Crisp stamping. Correct beveled edge on spacer. Coated black. Officially Licensed GM Restoration Parts.	NVHQW747	36.72
	1969-1972 Smog Pump Bracket	This is a factory style smog pump bracket used on all 1969-75 Chevrolet models with 302, 350 or 400 small block motors.	NVPPZSPB6975	79.98
	1969-1972 Upper Alternator Bracket (Small Block)	Accurate heavy weight clean stamping. Technically correct accessory hole placements for listed applications. Use with all long neck water pump small block engines. Coated black. Officially Licensed GM Restoration Parts.	NVHQW570	52.72
	1969-1974 A/C Compressor Front Plate Bracket (Small Block)	(1969 - 1982 CHEVY) SMALL BLOCK A/C COMPRESSOR FRONT PLATE BRACKET - MOUNTS ON FRONT OF COMPRESSOR HAS ADJUSTMENT SLOT GM #: 3932433FITS: 1969-82 CHEVROLET VEHICLES WITH 307, 350, or 400 CUBIC INCH SMALL BLOCK ENGINES	NVPPZ3932433	31.98
	1969-1974 A/C Compressor Front Support Bracket (Small Block)	FRONT AIR CONDITIONER COMPRESSOR SUPPORT BRACKET FITS SMALL BLOCK MOTORS 307/350/400 GM # 3932432	NVPPZ3932432	79.98
	1969-1974 Compressor Front Bracket (Small Block)	Replacement front air conditioning compressor bracket for Impala and full size B-body models. Not compatible with big block models. GM #3932433	NVIC3932433	41.98
	1969-1974 Fan Spacer GM#3947132	(1969 - 1979 GTO/LeMans) FAN SPACER 1-15/16" & 1-1/2 BOLT SPACING (FOR CARS W/O CLUTCH) - GM # 3947132	NVPPZCS6822Z	63.98
				



	1969-1974 Power Wheel Adjust Bracket (Small Block)	Excellent quality reproduction manufactured to duplicate the original in both fit and appearance.	NVD1072J	51.00
	1969-1974 Rear AC Compressor Bracket Support (Small Block)	Reproduction rear AC compressor bracket support for 1969-76 Nova models with small block engine. Applications: 1969-76 Nova w/Small Block, 1973 Nova w/6 Cylinder	NVIC3932435	62.14
	1969-1974 Smog Pump Bracket (Big Block)	New OEM first design smog pump bracket. Used on all Camaro, Chevelle, Nova, El Camino, Monte Carlo with big block. 396, 402, 427, 454	NVPPZ630	79.98
	1970-1972 FRONT A/C COMPRESSOR BRACKET - 2nd DESIGN	HEAVY CAST IRON BRACKET MOUNTS TO FRONT OF HEAD BIG BLOCK 2ND DESIGN (GM PART # 3969917)	NVPPZUACB6975	105.58
	1970-1972 FRONT A/C COMPRESSOR PLATE BRACKET - 2nd DESIGN	MOUNTS ON FRONT OF COMPRESSOR HAS ADJUSTMENT SLOT ON BOTTOM BIG BLOCK 2ND DESIGN (GM PART # 3969916)	NVPPZFCPB7075A	39.98
	1970-1972 POWER STEERING BRACKET 2 PC SET - BIG BLOCK	SET INCLUDES THE UPPER BRACKET WITH PART # 3967420, AND THE LOWER BRACKET GM # 3967422. THE UPPER BRACKET IS USED ON 1970 71 72 BIG BLOCK ONLY, AND HAS THE GM NUMBER 3967420 STAMPED ON IT. FITS ALL 396, 427, 454, LS5, LS6, L89 MOTORS	NVPPZ632	133.55
	1970-1972 Power Steering Pump Bracket (Big Block)	Reproduction power steering pump bracket which is required when mounting the power steering pump on Big Block applications.	NVICK7422	82.30
	1970-1972 REAR A/C COMPRESSOR PLATE BRACKET - 2nd DESIGN	MOUNTS ON BACK OF COMPRESSOR AND IS A TRIANGULAR SHAPED BRACKET THAT ATTACHES COMPRESSOR TO THE ADJUSTMENT BRACKET BIG BLOCK 2ND DESIGN (GM PART # 396911)	NVPPZRCPB7075A	63.98
	1970-1972 SIDE A/C COMPRESSOR BRACKET - 2nd DESIGN	GOES FROM TOP OF COMPRESSOR TO INTAKE BIG BLOCK 2ND DESIGN (GM PART # 3969910)	NVPPZSCSB7075A	35.18
	1970-1974 Power Steering Pump Spacer	Power Steering Pump Spacer: Correct spacer which keeps the power steering pump from making contact with the front support.Applications:1970-1972 396, 402, 4541973-1979 250	NVIC3967424	10.06
	1971-1972 Small Block Power Steering Adjustor Bracket	Correct reproduction of the original small block power steering bracket	NV3959558	53.74





Early Birds specializes in hard-to-find Chevy Nova parts and has been serving you for over 25 years.  
Call us at 1 800 463 0546 Mon - Fri 9:00 AM - 4:00 PM (EST) - we know our cars!  
Fax your order: (416) 630 8794

Our Mailing Address:  
Early Birds  
25 Saunders Road, Unit 9  
Barrie, Ontario  
L4N 9A7  
Canada