




Early Birds

Your GM Muscle Car Headquarters

Visit www.early-birds.ca for most up-to-date catalog this copy was generated March 28 2024

Chevy Nova / Fuel System and Exhaust / Smog System & Parts

Picture	Product name	Description	SKU	CAD
	1967 Crankcase Vent Tube	Reproduction of the original crankcase vent tube used with 1966-67 Chevy II / Nova models. Original application includes use with closed positive ventilation system on 1967 models with 283 or 327 with closed positive vent w/o A.I.R. This tube installs on the rear most section of the block directly behind the distributor. Installation stud included.	NVICPR111K	310.78
	1967-1969 Reproduction Smog Tubes - PR	Reproduction smog tubes also known as air injection reactor tubes which are manufactured exactly as original! These tubes are cosmetically correct in every detail! Each tube is manufactured to exact factory specifications including correct bends and outlets for installation onto the exhaust manifold. A correct threaded outlet head is installed for easy installation of the smog pump check valves. Original GM tubes are finished in the correct zinc plating. Call for multiple colours, styles or patterns or choose online	NVICR34748	218.38
Early Birds Order Hotline: 1 800 463 0546				
	1968-1972 SMOG CHECK VALVE	We now have the correct looking check valve for most all GM Chevrolet models, Camaro, Corvette, Impala, Chevelle, El Camino and Nova. Fits the following motors: 302 327 350 400 454 L78 L89 LS6 LS5 Z28 Copo. This is different than what was available for GM as a replacement or aftermarket. It is gold anodized like original and is the most correct looking smog check valve on the market.	NVPPZSCV68	63.98
	1968-1972 Smog Pump Fan (Correct White)	This fan is used on all GM models where high performance smog systems were used. This fan is high quality with the correct opaque/white and looks & feels like original.	NVPPZSF68A	127.98
	1969-1970 Air Injection Hose Sets	Includes hoses to check valve on AIR tube. Correct lengths of thick walled hoses to replace missing or cracked originals. Includes 4 correct tower hose clamps for mounting. Call for multiple colours, styles or patterns or choose online	NVICSH69	62.14
	1969-1972 SMOG DIVERTER ELBOW	New reproduction GM # 3942533 diverter elbow for the smog pump. This is the OEM aluminum elbow that bolts to the smog pump, and the diverter valve mounts on the opposite side. Used on most all 1969-76 Chevrolet applications Z28 / LS6 / LS5 / L78 / L89 302 / 350 / 396 / 454 engines.	NVPPZ3942533	63.98
				

	1969-1972 Smog Pump Bracket	This is a factory style smog pump bracket used on all 1969-75 Chevrolet models with 302, 350 or 400 small block motors.	NVPPZSPB6975	79.98
	1969-1972 Smog Pump Pulley - Deep 1 Groove	Deep 1 groove pulley fits 69-72 Camaro / Z28 / Chevelle SS / LS5 / LS6 / L78 / L89 / Corvette & Impala big block motors. Has 3932458DA stamped on it.	NVPPZ3932458	127.98
	1969-1974 Smog Pump Bracket (Big Block)	New OEM first design smog pump bracket. Used on all Camaro, Chevelle, Nova, El Camino, Monte Carlo with big block. 396, 402, 427, 454	NVPPZ630	79.98

Early Birds specializes in hard-to-find Chevy Nova parts and has been serving you for over 25 years.
Call us at 1 800 463 0546 Mon - Fri 9:00 AM - 4:00 PM (EST) - we know our cars!
Fax your order: (416) 630 8794

Our Mailing Address:
Early Birds
25 Saunders Road, Unit 9
Barrie, Ontario
L4N 9A7
Canada