



1 800 463 0546

Early Birds Your GM Muscle Car Headquarters

Visit www.early-birds.ca for most up-to-date
catalog this copy was generated March 29 2024

Coronet/Super Bee / Brakes / Brake Boosters & Parts

Picture	Product name	Description	SKU	CAD
	1966-1970 Booster Firewall Plate. w/Pedal linkage	1966-1970 B Body Mopar Booster Firewall Plate. Pedal linkage is also included.	COMBHWK8536-1	134.61
	1966-1970 Power Brake Booster Conversion Kit, Disc/Drum applications (w/o proportioning valve)	1966-1970 B Body Mopar Booster Conversion Kit O.E.M Style. Comes complete with OEM Style brake booster in black with period correct master cylinder with 2225621 casting. Firewall bracket and pedal linkage are also included.	COMBBCK8536-1	640.23
	1966-1970 Power Brake Booster Conversion Kit, Disc/Drum applications (w/proportioning valve)	B Body Mopar Booster Conversion Kit O.E.M Style. Comes complete with OEM Style brake booster in black with period correct master cylinder with 2225621 casting. Includes O.E.M Style proportioning vale. Firewall bracket and pedal linkage are also included.	COMBBCK8536-2P	784.39
Early Birds Order Hotline: 1 800 463 0546				
	1966-1971 8" Dual Booster Conversion Kit	Dodge Plymouth 1965-70 A-Body, 1965-74 B & E Body Bracket & Pedal Assembly 8 inch Dual Diaphragm Booster Bracket and Master Cylinder	COPBUP6570	357.21
	1966-1971 9" Single Diaphragm Power Brake Booster	9" single-diaphragm booster. 7 lbs.	COPB9002	235.18
	1966-1972 Brake Master Cyllnder, Drum/ Drum	1962-1972 Mopar B&E Body Booster Conversion Kit including 8Ø booster, master cylinder, proportioning valve kit with lines, bracket & mounting hardware. Kit comes complete with firewall bracket, pedal rod extension and clevis. Easily convert your manual brakes to power brakes with this easy to install kit. This system is designed to for a Disc/Disc system. Disc/disc or drum/drum systems are available.	COMBMC5621	167.47
	1966-1972 Power Brake Booster Conversion Firewall Bracket	1962-1972 Mopar B&E Body Booster Conversion Firewall Bracket	COMBBPR6570	92.21
	1966-1972 Power Brake Booster Conversion Kit, Disc/Drum applications	1962-1972 Mopar B&E Body Booster Conversion Kit including 8Ø booster, master cylinder, proportioning valve kit with lines, bracket & mounting hardware. Kit comes complete with firewall bracket, pedal rod extension and clevis. Easily convert your	COMBMP-200	283.01

manual brakes to power brakes with this easy to install kit. This system is designed to for a Disc/Disc system. Disc/disc or drum/drum systems are available. Available in various looks and materials, choose your Master cylinder material/finish, Master cylinder bail type, and brake booster/bracket finish.
Call for multiple colours, styles or patterns or choose online



1966-1974 Master Cylinder Gasket - 2pc

Factory-style replacement master cylinder gasket for most models with or without power brakes. Applications: A-Body 1960-1976 B-Body 1962-1974 E-Body 1970-1974

COREMCLR-GSK- 15.98
065



1966-1974 Universal 9" Single Diaphragm Booster

Universal 9" Single Diaphragm Power Brake Booster Black Finish 3"-3/8 Center To Center Bolt Spacing (Firewall) 3"-3/8 Center To Center Bolt Spacing (Master Cylinder) 3/8-24 Threaded Rod Specs Booster Size-9" Single Booster Finish-Black Master Cylinder Bolt Spacing-3"-3/8 Center To Center Bolt Spacing Firewall Bolt Spacing-3"-3/8 Square Bolt Spacing Rod Thread-3/8"-24 Rod Length-4" Box Size-14x11x15 Weight-9 Lbs.

COIPB9002B 235.18



1967-1970 Mopar Power Brake Booster Check Valve

POWER BRAKE BOOSTER CHECK VALVE

COPPCB10002J 39.98



1968-1970 B-Body Brake Booster Firewall Bracket

Premium quality reproduction brake booster firewall bracket for 1968- 70 B-Body Dodge and Plymouth models. This bracket installs onto the firewall to hold the brake booster wiring and hoses. 1 needed per vehicle

COICMB1942 60.46



1968-1970 B-Body Master Cylinder Firewall Bracket

Premium quality reproduction master cylinder firewall bracket for 1968-70 B-Body Dodge and Plymouth models. This bracket snaps into place between the master cylinder brace and the firewall to hold the wiring and hoses. One needed per vehicle.

COICMB1941 75.58



1971-1974 Booster Firewall Plate. w/Pedal linkage

1971-1974 Mopar B Body & 1970-1974 E B Body Mopar Booster Firewall Plate. Pedal linkage is also included.

COMBHWK8536-2 134.61



1971-1974 Power Brake Booster Conversion Kit, Disc/Drum applications (w/o proportioning valve)

1971-1974 Mopar B Body & 1970-1974 E Body Booster Conversion Kit O.E.M Style. Comes complete with OEM Style brake booster in black with period correct master cylinder with 2225621 casting. Firewall bracket and pedal linkage are also included.

COMBBCK8536-2 640.23



1971-1974 Power Brake Booster Conversion Kit, Disc/Drum applications (w/proportioning valve)

1971-1974 Mopar B Body & 1970-1974 E B Body Mopar Booster Conversion Kit O.E.M Style. Comes complete with OEM Style brake booster in black with period correct master cylinder with 2225621 casting. Includes O.E.M Style proportioning vale. Firewall bracket and pedal linkage are also included.

COMBBCK8536-1P 773.79
V

Early Birds specializes in hard-to-find Coronet/Super Bee parts and has been serving you for over 25 years.
Call us at 1 800 463 0546 Mon - Fri 9:00 AM - 4:00 PM (EST) - we know our cars!

Fax your order: (416) 630 8794

Our Mailing Address:
Early Birds
25 Saunders Road, Unit 9
Barrie, Ontario
L4N 9A7
Canada