

Early Birds Your GM Muscle Car Headquarters


Visit www.early-birds.ca for most up-to-date catalog this copy was generated March 28 2024

Duster/Valiant / Engine & Compartment / Brackets & Spacers

Distance	Product access	Description	OKL	04.0
Picture	Product name	Description	SKU	CAD
111 001	1970-1972 Power Steering Bracket Set (Federal,Small Block)	Replacement federal power steering brackets for 1970-72 Small Block engines with aluminum water pumps. These are for A/C and non-A/C applications. Replace those old rusted or missing brackets with new power steering brackets. Includes(3) OE correct 5/16-18 place bolts for pump to bracket attachment and the bolt, conical washer and spacer used to sandwich the brackets to the pump body. Extra washer provided for use on bolt in adjusting slot. Brackets are powder coated in low gloss black for better appearance and longer life.		142.78
			D)//DMD/2007	
	1970-1974 Alternator Slider Bracket (all V8 except Hemi)	Reproduction alternator slider bracket. Will fit and install on all 1966-74 Mopar V8 engines, excluding Hemi.	DVICMD4067	20.14
2	1970-1974 Coil Mounting Bracket (small block)	Reproduction ignition coil mounting strap for all 1962-74 Mopar	DVICMD7577	36.94
		models with a small block engine (excluding 6-barrel equipped engines). $ \\$		
Early Birds Order Hotline: 1 800 463 0546				
	1970-1974 Power Steering Bracket Set (Saginaw,Small Block,w/aluminum water pump)	Saginaw power steering mounting bracket for 1970 and later A-Engines (with aluminum water pump), Magnum crate engines, and Commando engines. Features low mount design and is compatible with most models. Use with Saginaw pump nutted or press on shaft. Works with ICMD2381, ICMD2383 power steering pulleys with spacer package ICMD47207. For AC or non AC applications. Available in black powder coated finish.	DVICMD47208	194.76
000000	1970-1974 Saginaw Pulley Conversion Bolt Set	If your Mopar small block has a Saginaw pump but no power steering pulley, this special bolt and spacer set is the solution! This set mounts big block power steering pulleys: ICMD2381, ICMD2383 on your small block. Compatible with ICMD47208 or factory Saginaw low power steering bracket set, resulting in perfect alignment!	DVICMD47207	25.18
Emperinage ons, statut part ray after	1970-1974 Small Block Alternator Bolt & Spacer Kit (w/alum water pump, w/o AC)	Each kit includes bolts, washers and spacers needed to mount the alternator and brackets.Note: "With 3-hole alternator bracket. Must use #ICMD2424 with this kit.	DVICMD2435	35.26
	1970-1974 Small Block Alternator Bracket Set (w/aluminum water pump #3420037)	Replacement alternator bracket set for 1967-74 Mopar models with a small block engine with aluminum water pump. Each set contains all brackets required to correctly mount the alternator	DVICMD2428	67.18

contains all brackets required to correctly mount the alternator exactly as the factory required. Featuring a total of 7 pieces, each

set includes a correct length bolt, thick flat washer and three spacers as well as a black-dipped triangle bracket and adjusting bracket for a truly authentic appearance.Applications:1970-74 Mopar Models (ALL) W/ Small Block W/Aluminum Water Pump, Water Pump Casting # 3420037



1970-1976 Mopar Alternator Spacers - PR

Premium quality reproduction alternator spacers for most Mopar DVICMF1746 models. Alternator spacers fit between the alternator bracket and the block. Fits big block and small block Dodge and Plymouth models. Sold as a pair. One pair required.



Bolt Set

1970-1976 Mopar Saginaw Power Steering Pump Mounting Premium quality set includes: all bolts, washers, nuts, and studs DVICMD47279 required to mount the Saginaw power steering pump to your small or big block engine, including the unique studs that have been out of production for years

48.70

20.14



1970-1976 Power Steering Bracket Set (Saginaw,Small

These power steering pump brackets are designed for 1970-76 DVICMD2603 Mopar small block engines, fit both styles of Saginaw pumps and are compatible with or without AC applications. Includes correct hardware to mount brackets to the power steering pump and attach the assembly to the water pump housing. Features a black powder coated finish for long life.


142.78



(Saginaw)


1970-1976 Power Steering Pump Mounting Bolt Set These sets come with all the bolts, washers and nuts required to DVICMD47205 mount the Saginaw power steering pump including the unique black studs that have been out of production for years. Compatible with all small and big block power steering pumps and mounting brackets, SAE 1979 or earlier. Available in black

44.51



1970-1976 Sanden SD7H AC Compressor Bracket Set (small Upgrade the power-robbing factory AC compressor in your Mopar DVICMN410703 with an efficient Sanden. This set is for models with 1970-76 273-360 small block engines with factory AC and original RV2 or C171 compressor. Mounts only Sanden SD7H compressors. Fits most standard, shaker, and aftermarket hoods. Note: Need to change compressor hoses, o-rings, thermostat/clutch cycling switch, expansion valve, filter-drier for R134a refrigerant and a R134a service port kit for correct installation.

272.14



block, w/o AC)

1970-1976 Sanden SD7H AC Compressor Bracket Set (small Add an efficient Sanden AC compressor to your Mopar without DVICMN410704 factory AC with these upgrade sets. This set is for models with 1970-76 318-360 small block engines without factory AC and with or without power steering. Mounts only Sanden SD7H compressors. Fits most standard, shaker, and aftermarket hoods.Important: This bracket set is specifically designed for 6 bbl intakes or other intakes that do not feature the front bolt boss on top of the intake. Cannot be used in conjunction with intakes

193.18

Early Birds specializes in hard-to-find Duster/Valiant parts and has been serving you for over 25 yearshat feature the front bolt boss.

Call us at 1 800 463 0546 Mon - Fri 9:00 AM - 4:00 PM (EST) - we know our cars!

Call for multiple colours, styles or patterns or choose online

Fax your order: (416) 630 8794

Our Mailing Address: Early Birds 25 Saunders Road, Unit 9 Barrie, Ontario L4N 9A7

Canada